



Plan a safe installation

General guidance for industrial heated hose assemblies.

Scope

This guide supports planning and maintenance communication. It does not authorise installation of an unidentified assembly or replace the machine instructions, site procedures or the supplied hose specification.

Before work is scheduled

Obtain the hose identification, accepted specification, wiring drawing, applicable machine manual and adhesive safety data sheet. Confirm the personnel responsible for installation and the site's method for controlling hazardous energy.

Hazard	Planning requirement
Stored energy	A stopped machine can retain pressure or electrical energy. Authorised personnel must apply the machine-specific isolation procedure and verify a safe condition before servicing.
Hot material and surfaces	Plan suitable guarding and protection using the equipment instructions and medium safety data sheet. Do not assume the hose surface is safe to touch.
Wrong electrical connection	Have a qualified person verify the sensor, pinout, supply and protective arrangements. Never use plug appearance as proof.
Unknown operating limit	Do not commission the hose until the rating and intended conditions have been reconciled.

Stop condition

If identification is missing, specifications conflict or visible damage is present, keep the assembly out of service and request a technical review. Do not resolve conflicting ratings by choosing the higher value.



Routing and installation review

Use the approved drawing and the model-specific bend radius.

Mechanical arrangement

Avoid twisting, sharp bends, crushing and tensile loads at the ends. Plan supports that do not pinch the hose. Keep the route clear of moving machinery, sharp edges and damaging contact surfaces. Do not use the electrical cable to lift or pull the assembly.

Connections and controls

Verify fitting and seal compatibility before assembly. Torque, sealants, electrical test limits and connector assignments must come from the approved model documents, not this general guide. Confirm that the controller and sensor are suitable for each other.

Review point	Required record
Length and route	A drawing or photograph showing the intended installation and any movement.
Bend and support requirements	The hose-specific limits and support arrangement.
Mechanical interfaces	End A and End B fitting and seal identification.
Electrical interface	Approved connector pinout, sensor and supply details.
Operating conditions	Accepted temperature, pressure, medium and environment.
Commissioning responsibility	The authorised technician and applicable machine procedure.
Do not commission a hose with missing connection information. Ask for the correct drawing rather than modifying the connector, sensor or protective circuit.	



Observation, care and service

Use site procedures for start-up, shutdown and maintenance.

Initial operation

A qualified person should monitor initial heating under the equipment's prescribed commissioning procedure. Keep operating conditions within the approved limits. Do not bypass alarms or apply external flame to a blocked hose.

Checks during use

Include hose condition, route and visible connection condition in the site inspection plan. Record new abrasion, deformation, leakage, connector damage or unusual temperature behaviour. Inspection frequency should reflect service conditions and the model instructions.

When an abnormal condition appears

For leakage, visible damage, smoke, electrical faults or uncontrolled heating, stop use through the appropriate site procedure and prevent unintended restart. Do not touch escaping material or search for a leak by hand. Follow the site emergency procedure where necessary.

Before disconnection or maintenance

Authorised personnel must control all hazardous energy, address stored pressure and verify isolation using the equipment-specific procedure. A control-panel OFF command alone is not proof of isolation. Thermal conditions must also be made safe as required by the procedure.

Repair and cleaning

Do not cut, splice, rewire or open the assembly without written model-specific instructions. Use only the approved cleaning process and medium. Obtain return instructions before shipping a used hose; identify any remaining process material.

Documentation is part of maintenance

Retain the hose reference, accepted specification, commissioning record and service history together. Contact us with these records when requesting assistance.

Report a problem clearly

A service report assists assessment; it does not replace on-site fault diagnosis.

Observed condition	Send with the service enquiry
No heating / slow heating	Label photo, machine model, alarm text, controller settings and when the condition began.
Unstable temperature	Sensor reference, recorded readings, process changes and approved configuration.
Reduced flow	Medium details, operating history and equipment alarm information.
Leakage or physical damage	Safe-distance photographs, location, date discovered and whether the hose remains isolated.
Connector concern	Clear external photos and the approved wiring reference; no live testing requested.

Record before contacting us

Order reference; hose identification; installation date; operating hours if recorded; normal temperature and pressure; symptom timing; and any changes to the medium, machine or installation.

Technical reference basis

General principles were checked against manufacturer guidance and hazardous-energy guidance. These sources do not certify Gongbang products or supply their ratings.

[Winkler: heated hose installation and operation guidance](#)

[Protherm: hose length and routing considerations](#)

[OSHA: control of hazardous energy \(US reference\)](#)

The installation jurisdiction and site rules must be assessed separately. Obtain model-specific technical review before using this guide as part of an operating document set.

Discuss your hose requirement

WhatsApp / Singapore: +65 94378277

juliangoh85sg@hotmail.com

www.gongbangptfe.com